




Assembly Instruction

Mini Trampoline 140



IMPORTANT

Read the following statements and warnings to avoid serious or fatal injury.

Warning.

- Max 45 kg.
- Only for domestic use.
- Only one user. Collision hazard.
- The net should be replaced every year.
- Adult supervision required.
- No somersaults.
- Always close the safety net opening before jumping.
- Read the instructions.
- The trampoline shall be assembled by an adult in accordance with the assembly instructions and then checked before the first use.
- Do NOT wear shoes whilst bouncing on the trampoline
- Empty pockets and hands before jumping.
- Always jump in the middle of the mat.
- Do not use when the mat is wet.
- Do not eat while jumping.
- Do not exit by a jump.
- Limit the time of continuous usage (take regular breaks).
- Do not use in strong wind conditions and secure the trampoline.
- Avoid bouncing too high. Stay low until you can control your bounce and repeatedly land in the centre of the trampoline.
- Do not use the trampoline as a springboard to other objects. Use the trampoline only for bouncing.
- Keep objects away that could interfere with the person jumping.
- Do not bounce directly after eating.
- Do not attempt knee drops as these can cause injury.
- Clothing should allow plenty of body freedom. Loose shirts or skirts should be avoided to reduce risk of entanglement.
- Buckles or jewellery should not be worn as these could damage the trampoline bed and cause injury.
- Supervising adults should warn children prior to commencing play on the trampoline NOT to crawl under or try to enter the enclosure whilst the trampoline is in use.
- Parents or supervising adult must ensure children wear appropriate clothing to avoid any potential dangers for the child whilst using the trampoline.

Placement of the trampoline

Do not place the trampoline on a concrete floor or other hard surfaces. The ideal placement is a level, stable surface like a lawn. There must be at least 2 meters of space around the trampoline. Check that there are no wires, tree branches, fences or other possible hazards above and around the trampoline. The trampoline should not be placed near any pools, swings, slides, climbing frames or other obstructive installations. The trampoline is not intended to be buried into the ground.

Weather conditions

The trampoline should not be used when wet. In winter conditions, please disassemble the trampoline and store all fabric parts (mat, foam pad, safety net) inside. In strong wind conditions, disassemble the foam pad and safety net and secure the trampoline to the ground using Ground Stakes/Anchors (sold separately).

How to use

Take it easy at first. Don't try difficult moves.

Do not jump when tired - this increases the risk of injury. Be sure to wear proper shoes, e.g. gym shoes, or be barefoot when jumping.

Never step on the frame pad. It is not constructed to support the weight of a person. Never dismount by jumping off the trampoline. Always climb off. Don't use the trampoline under the influence of drugs or alcohol.

Always have someone else watching while you jump. If you should injure yourself you will have someone to assist you.

Always start your jump at the centre of the mat. If you land more than 30 cm away from the edge of the logo, stop your jump immediately!

Restart your jump at the centre of the mat.

CARE AND MAINTENANCE

This trampoline was designed and manufactured with quality materials and craftsmanship. If proper care and maintenance is provided, it will provide all jumpers with years of exercise, fun, and enjoyment as well as reduce the risk of injury. Please follow the guidelines listed below. Installments of additional accessories must be carried out as per manufacturer's instructions.

This trampoline is designed to withstand a certain amount of weight and use. Please make sure that only one person at any one time uses the trampoline. Jumpers should either wear socks, gymnastics shoes, or be barefoot when using the trampoline. Please be aware that street shoes or tennis shoes should NOT be worn while using the trampoline. In order to prevent the trampoline mat from getting cut or damaged please do not allow any pets onto the mat. Also, jumpers should remove all sharp objects from their person prior to using the trampoline. Any type of sharp or pointed objects should be kept off the trampoline mat at all times. Regularly check that nuts and bolts are securely tightened, since they may come loose over time. Check that all spring-loaded (pit pin) joints are still intact and cannot become dislodged during play; Check all coverings and sharp edges and replace when required Check that mat, padding and enclosure are free from defects.

Always inspect the trampoline before each use for worn, abused or missing parts. A number of conditions could arise that may increase your chances of getting injured. Please be aware of:

- Punctures, holes, or tears in the trampoline mat
- Sagging trampoline mat
- Loose stitching or any kind of deterioration of the mat
- Bent or broken frame parts, such as the legs
- Broken, missing, or damaged springs
- Damaged, missing, or insecurely attached frame pad
- Protrusions of any types (especially sharp types) on the frame, springs, or mat

Note. Sunlight, rain, snow and extreme temperatures reduce the strength of these parts over time.

IF YOU FIND ANY OF THE PREVIOUS CONDITIONS, OR ANYTHING ELSE THAT YOU FEEL COULD CAUSE HARM TO ANY USER, THE TRAMPOLINE SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION (S) HAS BEEN RESOLVED.

Do not modify the trampoline or any of its parts

The net should for safety's sake be replaced every year.

MOVING THE TRAMPOLINE













If you need to move the trampoline, two people should be used. All connector points should be wrapped and secured with weather resistant tape, such as duct tape. This will keep the frame intact during the move and prevent the connector points from dislocating and separating. When moving, lift the trampoline slightly off the ground and keep it horizontal to the ground. For any type of other move, you should disassemble the trampoline.

Keep this instruction manual.


Assembly

Please read the assembly instructions fully before starting to assemble the trampoline. On occasion it is advisable to have two people assembling it together.

The reference No. of each part will be used in the instructions to guide you.


Ref No.	Diagram	Description	Quantity
1		Trampoline Mat with Enclosure Netting	1
2		Frame Pad	1
3		Top Rail	6
4		Leg with End Cap	6
5		Upper Frame Tube with Foam	6
6		Lower Frame Tube with Foam	6
7		Tube Cap	6
8		Self-Locking Screw	24
9		Elastic Cord	30
10		Elastic Cord Loading Tool	1
11		Allen Wrench	1
12		Anti-Slip Stickers (optional)	6

STEP 1




NOTE: part no. 12 is to be applied only when product is used indoors.

STEP 2










STEP 3




STEP 4


There is a total of 30pcs Elastic Cords (#10). For even distribution of tension and ease of assembly, the Elastic Cords must always be installed on opposite sides of the mat in an alternating manner.




STEP 5




STEP 6



STEP 7




STEP 8





Samlevejledning Minitrampolin 140



VIGTIGT

Læs følgende erklæring og advarsler for at undgå alvorlige eller fatale ulykker.

Advarsel.

- Maks. 45 kg.
- Kun til privat brug.
- Kun en bruger ad gangen. Risiko for kollision.
- Nettet bør udskiftes hvert år.
- Opsyn af en voksen er påkrævet.
- Ingen kolbøtter/saltomortaler.
- Luk altid sikkerhedsnettets åbning, inden du begynder at hoppe.
- Læs vejledningen.
- Trampolinen skal samles af en voksen ifølge samlevejledningen og derefter tjekkes før brug.
- Du må IKKE hoppe i trampolinen med sko på.
- Tøm lommerne, og hav ikke noget i hænderne.
- Hop altid på midten af dugen.
- Må ikke bruges, hvis dugen er våd.
- Spis ikke, når du hopper
- Hop aldrig ned fra trampolinen.
- Benyt trampolinen i begrænset tid (hold jævnligt pauser).
- Må ikke bruges i stærk blæst. Fastgør trampolinen.
- Lad være med at hoppe for højt. Hop lavt, indtil du kan holde balancen og gentagne gange lander i midten af trampolinen.
- Brug ikke trampolinen som springbræt til andre genstande. Brug kun trampolinen til at hoppe i.
- Hold genstande, der kan komme i vejen for den, der hopper, på afstand.
- Lad være med at hoppe lige efter, at du har spist.
- Prøv ikke at lande på knæene, da det kan forårsage skade.
- Din påklædning bør give dig god bevægelsesfrihed. Løse bluser eller kjoler bør undgås, så du ikke risikerer at blive viklet ind i tøjet.
- Tag bæltespænder og smykker af, da de kan beskadige dig selv og trampolinen.
- Voksne, der holder opsyn, bør advare børn før brug af trampolinen om IKKE at kravle under den eller prøve at gå op på den, mens den er i brug.
- Forældre eller voksne, som holder opsyn, skal sørge for, at børnene bærer passende beklædning, når de hopper i trampolinen, for at undgå risici for skader.

Placering af trampolinen

Placer aldrig trampolinen på et cementgulv eller andre hårde flader. Den bedste placering er på en jævn og stabil overflade som for eksempel en græsplæne. Der skal være et frit område på mindst to meter omkring trampolinen. Sørg for, at der ikke er nogen ledninger, grene, hegn eller andre mulige farer over og rundt om trampolinen. Trampolinen må ikke placeres tæt på pools, gynger, rutsjebaner, klatrestativer eller andre installationer, der udgør en risiko. Denne trampolin er ikke beregnet til nedgravning.

Vejrforhold

Trampolinen må ikke bruges, når den er våd. Skil trampolinen ad om vinteren, og opbevar alle stofdele (dug, skumkanter og sikkerhedsnet) indendørs. Fjern skumkanter og sikkerhedsnet ved stærk blæst, og fastgør trampolinen til jorden med pløkker/jordspyd (sælges separat).

Vejledning

Start langsomt. Forsøg ikke at lave svære øvelser.

Hop ikke i trampolinen, når du er træet. Det øger risikoen for skader. Sørg for at bære passende fodtøj, f.eks. gymnastiksko, eller hop med bare fødder.

Træd aldrig på sikkerhedsbetrækket. Det er ikke konstrueret til at kunne bære en persons vægt. Når du skal ned fra trampolinen, må du aldrig hoppe. Kravl altid af. Hop aldrig i trampolinen, hvis du har indtaget stoffer eller alkohol.

Der skal altid være andre til stede, når du hopper i trampolinen. Så er der nogen til at hjælpe dig, hvis du skulle komme til skade.

Begynd altid med at hoppe midt i cirklen. Hvis du lander mere end 30 cm fra kanten af logoet, skal du omgående holde op med at hoppe!

Begynd at hoppe på midten af dugen igen.

PLEJE OG VEDLIGEHOLDELSE

Trampolinen er designet og fremstillet af kvalitetsmaterialer og udsøgt håndværk. Ved korrekt vedligeholdelse vil den give brugerne mange års træning, sjov og glæde, samtidig med at risikoen for skader vil være mindre. Følg vejledningen nedenfor. Montering af yderligere tilbehør bør ske i henhold til leverandørens vejledning.

Trampolinen er designet til at kunne tåle en bestemt vægt og belastning. Sørg for, at kun én person bruger trampolinen ad gangen. Brugerne bør enten bruge strømper, gymnastiksko eller hoppe i bare fødder, når de bruger trampolinen. Udendørssko eller sportssko bør IKKE bæres, når trampolinen bruges. For at undgå beskadigelse eller huller i trampolindugen bør kæledyr ikke træde på dugen. Brugerne skal også fjerne skarpe genstande, som de måtte have på sig, før de bruger trampolinen. Der bør ikke medtages nogen former for skarpe eller spidse genstande, når trampolinen bruges. Tjek med jævne mellemrum, at skruer, møtrikker og bolte er strammet godt, da de vil løsne sig under brug. Sørg for, at alle fjederbelastede samlinger (fjederpinde) er intakte og ikke kan løsne sig under brug. Tjek alle beskyttelsesdele for skarpe kanter, og erstat dem, hvis det er nødvendigt. Sørg for, at dug, skumkanter og tilbehør ikke er defekte.

Undersøg altid trampolinen for slitage, forkert brug eller manglende dele før brug. Der kan opstå en række situationer, der kan øge din risiko for at komme til skade. Vær opmærksom på:

- revner eller huller i trampolindugen
- sunket trampolindug
- løse sting eller andre former for ødelæggelse af dugen
- bukkede eller knækkede rammedele, f.eks. på trampolinens ben
- ødelagte, manglende eller beskadigede fjedre
- ødelagte, manglende eller forkert monteret sikkerhedsbetræk
- fremspring af enhver art (især skarpe) på rammen, fjedre eller dugen

Bemærk. Sol, regn, sne og ekstreme temperaturer nedsætter delenes holdbarhed.

HVIS DU MENER, AT DISSE FORHOLD ELLER ANDET KUNNE FORÅRSAGE PERSONSKADE FOR BRUGERNE, BØR TRAMPOLINEN SKILLES AD ELLER SIKRES MOD BRUG, INDTIL FEJLEN(E) ER BLEVET UDBEDRET.

Foretag ikke ændringer af trampolinen eller nogen af delene

Af sikkerhedshensyn bør sikkerhedsnettet udskiftes hvert år

FLYTNING AF TRAMPOLINEN













Det kræver to personer at flytte trampolinen. Alle fæstningspunkter bør være sikret med vejrbestandig tape, såsom klæbetape. Dette vil holde rammen intakt, når den flyttes, og forhindre, at fastgørelsespunkterne ikke flytter sig eller går løs. Løft trampolinen lidt fra jorden for at flytte den, og hold den vandret med jorden. Trampolinen bør skilles ad ved al anden form for flytning.

Gem denne vejledning.


SAMLEVEJLEDNING

Læs samlevejledningen omhyggeligt, før du begynder at samle trampolinen. Det anbefales, at to personer samler trampolinen.

Hver dels referencenummer vil blive brugt her i vejledningen som en hjælp til dig.


Ref. nummer	Billede	Beskrivelse	Antal
1		Trampolindug med sikkerhedsnet	1
2		Sikkerhedsbetræk	1
3		Topramme	6
4		Ben med endeprop	6
5		Nedre rammerør med skum	6
6		Øvre rammerør med skum	6
7		Rørhætte	6
8		Selvlåsende skrue	24
9		Elastik	30
10		Elastik spændeværktøj	1
11		Unbrakonøgle	1
12		Antiskrid klistermærker (eventuelt)	6

Trin 1




BEMÆRK: del #12 skal kun monteres, hvis produktet anvendes indendørs.

Trin 2










Trin 3




Trin 4


Der er i alt 30 elastikker (#10). For jævn fordeling af spænding og nem montering, skal elastikkerne altid monteres skiftevis på dugens modsatte side.




Trin 5



Trin 6



Trin 7



Trin 8

Spænd fast på rørhætten
(#7).

